



### **Recommended specifications for stone base:**

- 1.) Excavate to make an 8 inch cavity using the overall stone base dimensions per TurfHound schematic.
- 2.) Place 2 inches of  $\frac{3}{4}$ " coarse stone or modified gravel.
- 3.) Surround the cavity with 6x6 PT.
- 4.) Place 6" of  $\frac{3}{4}$ " stone and compact down to 4".
- 5.) Place 2" of fines and tamp.
- 6.) We recommend using a spreader to spread 2" fine stone dust and roll or tamp until flat and level with existing grade.

### **NOTE:**

If you decide to go with pavers do NOT install until after the tee line is installed and screwed down.

We recommend using 2 1/2" TimberLok Heavy Duty Wood Screws one screw per 33" straight frame.



\*The TurfHound name and logo are registered trademarks of TurfHound, Inc.  
[www.turfhound.com](http://www.turfhound.com)