



Recommended specifications for stone base:

***Note: TurfHound recommends a concrete base because the harder the subsurface the safer and more consistent your TurfHound surface will perform. The TurfHound Team understands there can be budgetary and logistical reasons that may make a concrete base restrictive to the club.**

- Excavate to make an 8- inch cavity using the overall stone base dimensions per TurfHound schematic and level with the natural turf.
- Place 2 inches of ¾" coarse stone or modified gravel.
- Surround the cavity with 6x6 PT wood.
- Place 6" of ¾" stone and compact down to 4".
- Place 3" of fine and tamp to 2".
- We recommend using a spreader to spread fine stone dust and roll or tamp until flat and level with existing grade.
- The ability of a stone base to drain diminishes over time. A TurfHound Tee Line is a long-term solution so you must consider constructing a stone base with a proper drain line under the front, middle or back depending on the location and slope of your practice tee.
- We recommend using 2 ½" TimberLok Heavy Duty Wood Screws and secure one screw per 33" straight frame and corner frame components.
- If you choose not to use timber, you must use pavers or similar material and increase the width and length of the stone base by the number of rows you intend to install around the perimeter.

PAVERS:

If you decide to surround your tee line with pavers, we have experienced at installations that you will achieve a straighter look if you install the tee line first.

