



String Line Helpful Hints



- Use 2 Tapcon Bolts (4"x3/8"); 1 against the frame to anchor the frame and the other just offset to give extra support to help keep the string taught.
- As you can see we have come in about 1" as not all concrete pads are straight, and you want to leave yourself room to keep the frame on the concrete, straight and to allow you to bolt into every other grommet hole.
- Secure the other end the exact same way with the bolts.
- Walk the line to make sure the string is straight and, on the edge, as shown (above right).
- As you begin to bolt, and you see seams, cracks or concrete expansion cuts where the grommet should be secured with a Tapcon, do not secure at that section but secure into the grommet hole prior to and just after the joint/crack into the available grommet holes. Picture above shows there is no issue with securing a Tapcon in this seam/crack area.

*The TurfHound name and logo are registered trademarks of TurfHound, Inc.

www.turfhound.com