



Configuration for assembly TL080 Model 9'6" on center



Frame end cap assembly;

- 2 - 0" quick connects
- 2 - 33" straights
- 1 - 6" quick connects
- 1 - Right hand corner
- 1 - Left hand corner




Turf End Cap Assembly;

- 1 - 22.5" x 66" end caps
- 2 - 16.5" x 78" corner caps


Configuration for assembly TL080

Model 10'6" on center



Frame end cap assembly;

- 2 - 0" quick connects
- 2 - 33" straights
- 1 - 6" quick connects
- 1 - Right hand corner
- 1 - Left hand corner




Turf Assembly;

- 1 - 33" x 66" fairway panels
- 2 - 30" X 66" rough panels
- 3 - 16.5" X 87" front trim panels
- 4 - 16.5" X 87" back trim panels


Turf End Cap Assembly;

- 1 - 22.5" x 66" end caps
- 2 - 16.5" x 78" corner caps

Configuration for assembly TL080 Model




- Frame end cap assembly;
- 2 - 0" quick connects
 - 2 - 33" straights
 - 1 - 6" quick connects
 - 1 - Right hand corner
 - 1 - Left hand corner




- Turf End Cap Assembly;
- 1 - 22.5" x 66" end caps
 - 2 - 16.5" x 78" corner caps

Configuration for station assembly TL100 Model



Frame end cap assembly;

- 2 - 0" quick connects
- 2 - 33" straights
- 3 - 6" quick connects
- 1 - Right hand corner
- 1 - Left hand corner



Turf End Cap Assembly;

- 1 - 22.5" x 87" end caps
- 2 - 15.0" x 55.5" corner caps

