



# Configuration for assembly TL080 Model 9'6" on center




Frame end cap assembly;  
2 - 0" quick connects  
2 - 33" straights  
1 - 6" quick connects  
1 - Right hand corner  
1 - Left hand corner




Turf End Cap Assembly;  
1 - 22.5" x 66" end caps  
2 - 16.5" x 78" corner caps

## Configuration for assembly TL080 Model 10'6" on center




Frame end cap assembly;  
2 - 0" quick connects  
2 - 33" straights  
1 - 6" quick connects  
1 - Right hand corner  
1 - Left hand corner




Turf Assembly;  
1 - 33" x 66" fairway panels  
2 - 30" X 66" rough panels  
3 - 16.5" X 87" front trim panels  
4 - 16.5" X 87" back trim panels

Turf End Cap Assembly;  
1 - 22.5" x 66" end caps  
2 - 16.5" x 78" corner caps

# Configuration for assembly TL080 Model




Frame end cap assembly;  
 2 - 0" quick connects  
 2 - 33" straights  
 1 - 6" quick connects  
 1 - Right hand corner  
 1 - Left hand corner




Turf End Cap Assembly;  
 1 - 22.5" x 66" end caps  
 2 - 16.5" x 78" corner caps

# Configuration for station assembly TL100 Model



Frame end cap assembly;  
 2 - 0" quick connects  
 2 - 33" straights  
 3 - 6" quick connects  
 1 - Right hand corner  
 1 - Left hand corner



Turf End Cap Assembly;  
 1 - 22.5" x 87" end caps  
 2 - 15.0" x 55.5" corner caps